



HD Colorado


Sluit de antennekabel aan tussen de Cai-wandcontactdoos en de Ontvanger (SIGNAL IN)
 Sluit de ontvanger aan op de TV doormiddel van een Scart en / of een HDMI-kabel.
 Indien u met HDMI geen beeld ziet adviseren wij om voor de eerste keer de scartkabel te gebruiken (deze kiest vaak automatisch de juiste TV ingang).




Plaats vervolgens de smartcard in de ontvanger.



Plaats de batterijen correct in de afstandsbediening.



Zet de schakelaar aan de achterkant op "ON"
 Stop de netstekker in het stopcontact



Zet de ontvanger aan met de power toets op de afstandsbediening of op de ontvanger. Kies, afhankelijk van hoe u de ontvanger heeft aangesloten, de AV/SCART of HDMI ingang op uw TV. Raad hiervoor de handleiding van uw TV.



1. Taal



Kies de gewenste taal met de **Left/Right** toetsen.
 Druk de **OK** toets om te bevestigen en naar de volgende stap te gaan.

2. Zenders zoeken



U heeft hier de gegevens van uw kabelmaatschappij nodig. Zie voor de juiste frequentie/netwerknnummer, behorend bij uw woonplaats, de gegevens die u van uw kabelbedrijf heeft ontvangen. Een volledige lijst staat ook op www.stv.nl -> klik kabel -> klik instelfrequenties. Ga vervolgens naar "zoeken" en toets **OK** op de afstandsbediening. De Ontvanger zal de zenders gaan zoeken

Zoekt zenders



Nadat alle zenders gevonden zijn, wordt u gevraagd of de kanalen moeten worden opgeslagen. Kies hier "Ja" ("Ja" moet blauw oplichten) en druk **OK**.

3. Scherm



U komt nu in het menu voor de beeldinstellingen. Kies de instellingen die bij uw TV passen.

Bevestig door op de **OK** toets te drukken.


Uw ontvanger is nu ingesteld. U kunt nu genieten van Digitale Televisie

Wij wensen u veel kijkplezier.


Quick Installation Guide

HD Colorado


Connect the receiver to the cable outlet. Connect the receiver to your TV. You can choose between a Scartcable, and / or a HDMI cable. If you do not see a picture of your TV using the HDMI connection, you are advised to use the scart lead for first installation .




Insert a smartcard into your receiver.




Smartcard
Chip facing downwards!




Insert the correct batteries into the remote control unit.



Insert the powerlead into a wall socket. Flip the powerswitch on the back to "ON"



Power up your receiver using the power button of the RCU or the power button on the receiver. Choose the correct input on your TV according to your set up. See the manual of your TV for more details on choosing channels.




1. Language



Choose your language using the <-> buttons. Press **OK** to confirm your choice. A new menu item will be displayed.


2. Search channels



Enter the data specific to your cable operator. You can use data provided on the enclosed list or ask your cable operator for the correct data.


When all data is entered please press the **OK** button to start scanning for channels.

Scanning



Save any found channels pressing the **OK** button and go to the next menu item.

3. Display



This menu enables you to set up the TV. Press the **OK** button to confirm your choices.

Your receiver is ready to start watching TV or listen Radio.